PYLE® Home

PHIBT85BK

USER MANUAL

Sound Tower Bluetooth 2.0 Speaker with Built-in Subwoofer,

FM Radio and USB & SD Memory Reader

Sound Tower Bluetooth 2.0 Speaker with Built-in Subwoofer, FM Radio and USB & SD Memory Reader

PHIBT85BK

Preface:

1. Thank you for choosing our speaker with high quality wooden material made to create the perfect bass sound effect. Material used includes high density fiberboard which is moisture resistant. This beautiful and graceful structure creates fantastic sound quality and brings a cinema-like experience to your home.
2. before using the unit, be sure to read all operating instructions carefully so that can use it correctly.
3. The device does not contain any user replaceable parts, please let qualified personnel perform all the maintenance work

Important Safety Instructions:

A. Search for suitable location
B. Used in a well-ventilated space:
C. Avoid high temperature, moisture and dust

1. Make sure the speaker is on a horizontal and hard stable surface
2. Do not place unit near any potential heat sources (such as receptor and amplifier)
3. Do not put anything under this device

Put the device in a location with ventilation space in case of the interior temperature rise, make sure the ventilation space from the front and back side of the speaker at least 10 centimeters, left and right sides at least 5 centimeters.

1. The device should not be exposed to dripping or splashing and no objects filled with liquid such as vases shall be placed on the unit
2.The device shall not be placed near fire source(such as burning candle)
3. Disconnect the device from the AC power source when cleaning. Use Dust cloth to clean.

Power Safety:

1. The product should be operated only from the type of the power source indicated on the marking label.
2. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the device.
3. Do not overload wall outlets/power strip/surge protector, as this may cause a fire or electric shock
4. The power cord should be within reach, and easily accessible when need.

When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics at the original part. Unauthorized substitutions may result in fire or electric shock or other hazards.

2. Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is proper operating condition.

Functions Description:

1. MP3 decoding audio speaker 2.1
2. Built-in infrared receiving head, can switch to different functions by remote control
3. Support SD card disk and 3.5mm audio input.
4. With FM radio, available frequency:87.5-108MHz
5. LED display
6. Display Mode Functions: bluetooth, play, pause, SD, ,,MP3, MHZ, AU1 and AU2
7. Can display playing music number when insert U disk or SD card.

Front Side View:



1. LED
2. ⏮/VOL- - Previous song/ volume decrease
3. ⏭/VOL+ - Next song/ volume increase
4. ⏯ :play/pause
5. MODE: control USB、SD、FM、MP3-IN
6. EQ: Adjusting sound effect level
7. AUX: AUX1 and AUX2 input interface conversion
8. USB: U disk input
9. SD: SD card slot
10 MP3IN: line in audio input
11. IR: remote control receiving head

Back View:



1.AUX1 input interface
2.AUX2 input interface
3.FM antenna
4.Power switch

Operation Description:

1 . Plug power AC-110V
2.Push the power switch ON/OFF to ON position, it automatically enters to Bluetooth mode. Enter pass word "0000" to connect
3.Insert desired media to play music and LED has displaying function, press ⏮/VOL- or ⏭/VOL+ buttons to switch to previous and next song
4.Insert SD card to play music and LED has displaying function, press ⏮/VOL- or ⏭/VOL+

buttons to switch previous and next song

5. Short press the button ⏮/VOL- for previous song,press it for more than two seconds for volume decrease

6. Short press the button ⏭/VOL+ for next song,press it for more than two seconds for volume increase

7. Press the ⏯ button for play/pause

8. MODE: Bluetooth , USB,SD,MMC,MP3 in ,FM mode

9.EQ: press it for sound quality effect

10, AUX: press it to switch between AUX1 and AUX2

11. In FM radio mode: Press ⏯ button to search stations automatically, press ⏮/VOL- button for previous station, ⏭/VOL+ button for next station.

View for Remote Contol:

Remote control Functions:

1. POWER: power switch button

2. MUTE: Press to turn off the sound temporary, press again to turn the sound back

3. REPEAT: Set repeat playing mode

4. MODE: Switch USB/SD/FM/MP3IN

5. AUX: AUX1,AUX2 input interface

6. EQ: Sound effect level

7.0-9: 0-9 button numbers

8. ⏯ : play/pause

9. ⏭ /CH+ or ⏮ /CH-: previous/next song, CH+/CH- used in FM radio mode

10.VOL+: Volume increase

11:VOL-: Volume decrease

How to Use Remote Control:

a, Slide and lift up the battery door.
b. Install two"AAA"size batteries into the battery compartment as the figure below and the polarity markings inside battery compartment.
c, Replace and close battery door.

Technical Parameters:

USB/SD MP3 format
Bluetooth 2.0 specification, support A2DPV.12, AVRCPV1.4, HFP1.5 profiles
FM radio: 87.5-108.0 MHz

Speakers: Woofer: 5.25 inches， 8Ohm 30W

Baritone: 3 inches - 4 Ohm 10W
Tweeter: 1 inches - 8 Ohm 5W
RMS: 30W
S/N: 85dB
THD: ≤8%
Input impedance from port: 10 KOHM
Power: 110V 60Hz
Input Sensitivity: 980MV